

STRUCTURE OF THE VV ZEUS



Medical Grade Silicone Mouthpiece

Patented Full Length Coil Smileomizer®

Automatic Lithium ION Vapor Battery
*Vapor Zeus Manual Contains an activation button.

Advanced Microprocessor Controlling Power, Heat and Safety

Variable Voltage Adjusts From 3.2-4.8 Volts

WARNING: This product contains nicotine. Nicotine is an addictive chemical.

WARNING: This product contains nicotine. Nicotine is an addictive chemical.

DISCLAIMERS

- You must be legal smoking age in your state or territory to use this product. Nonsmokers, pregnant women and women who are breast feeding are strongly advised against using e-cigs.
- V4L products are not for smoking cessation and are not meant to treat, diagnose, cure, or mitigate any disease or condition.
- We make no claims that this product will help the user quit or lessen smoking.
- Please consult your physician before use or if you experience any negative side effects.

QUESTIONS?

If you have any questions, please contact us!

Phone: 847 944 8200

Email: support@vapor4life.com

Website: vapor4life.com

Vape Shop: 4080 Commercial Ave. Northbrook, IL 60062

Warranty Info: vapor4life.com/warranty

Follow us on social for additional sales and offers!

Facebook: facebook.com/officalV4L

Instagram: instagram.com/vapor4life_official

Twitter: twitter.com/vapor4life



VAPOR4LIFE®
VAPOR ZEUS VV USER MANUAL

FILL IT UP

It's imperative to fill your Smileomizer® properly the first time, so you'll get the perfect puff each and every time. Your patience will pay off big! As you fill, make sure to drip the e-juice slowly, so it can absorb all the way for a perfect hit. The first fill will be a little messy, but if you follow these instructions, your fills will last longer and taste better. You'll get the most natural smoking satisfaction you've ever had.



- Unscrew the mouthpiece from the Smileomizer®. Place the Smileomizer® on a flat surface that is covered with a napkin or tissue to absorb any e-juice.
- A small Smileomizer® will hold approximately 90 drops (3-3.5ml) when being filled the first time. A large Smileomizer® will hold approximately 120 drops (6-6.5ml)
- Carefully drip e-juice directly onto the cotton polyfill. Do not drip e-juice into the center tube. That is the air intake.
- After filling your Smileomizer® to capacity, let it sit for at least 15 minutes. It is worth the wait because the newest generation Smileomizer® has a higher performance coil.
- Replace the tip, hold your mouth to the top of the Smileomizer® and gently blow any excess liquid into a tissue. There won't be much if you filled it to the correct level.
- Wipe any excess liquid from the bottom of the Smileomizer® before reconnecting it with the battery. Once all the pieces are in place and the e-juice is fully absorbed, you will enjoy the finest vapor puffs you have ever had.
- This may seem like a lot of steps, but it is worth investing a few extra seconds to guarantee the flavor and vapor in every puff.

VAPE IT

**Always ensure clean surfaces on both the end of the cartomizer and battery before connecting.*

Zeus Variable Voltage Automatic

The Zeus Variable Voltage Auto is a premium automatic, variable voltage e-cig. Designed to provide a flexible and authentic vaping experience, the Vapor Zeus Variable Voltage Auto is ideal for a former smoker or vaper who wants to control over the way they vape. This sleek and sophisticated device can be adjusted from 3.2 to 4.8 Volts with a simple twist of the dial.

Zeus Variable Voltage Manual

The Zeus Variable Voltage Manual allows you to control your vaping experience with the push of a button. Combined with the variable voltage dial, you have complete control over the way you vape with the Zeus VV Manual.

- To turn Zeus Variable Voltage Manual on and off, press the button five times.
- When the Zeus Variable Voltage is activated, the button will light up.



CHARGE IT

- Screw battery onto USB cable.
- Connect cable to wall charging device.
- Plug into wall.
- LED on charging cable will display red while charging and green when complete.

Battery Size	Charge Time*
Small (650 mAh)	2-3 hours
Medium (900 mAh)	3-5 hours
Large (1100 mAh)	3-5 hours
X-Large (1300 mAh)	5-6 hours

*Charge time calculated with slim wall USB adapter shown below.



WARNING

- Only use the Vapor Zeus and Smileomizer® with Vapor4Life® equipment. If you use it with other equipment, and something malfunctions, your warranty will be voided.
- DO NOT drip liquid in center tube of cart.V
 - DO NOT fill cart when connected to battery.
 - ENSURE clean surfaces on both the end of the cartomizer and battery before connecting.